


POLE TOP



Standard Installation



Warning



Hot Surface





Flammable



High Voltage

TOOLS NEEDED:

-  3/16", 5/32", 9/64", & 5/64" Allen Wrench
-  Waterproof Wire Connectors

INSTRUCTIONS PERTAINING TO A RISK OF FIRE, OR INJURY TO PERSONS IMPORTANT SAFETY INSTRUCTIONS

Lighted fixture is HOT!

WARNING - To reduce the risk of FIRE OR INJURY TO PERSONS:

Turn off/unplug and allow to cool before replacing lamp/LED. Fixture gets HOT quickly! Contact only switch/plug when turning on. Do not touch hot lens, guard, or enclosure. Keep fixture away from materials that may burn. Do not operate the luminaire fitting with a missing or damaged shield. Do not touch the source at any time. Use a soft cloth or gloves. Oil from skin may cause damage.

SAVE THESE INSTRUCTIONS


IMPORTANT SAFETY INFORMATION - READ, FOLLOW, AND SAVE ALL SAFETY AND INSTALLATION INSTRUCTIONS

- Product must be installed by a qualified person in a manner consistent with its intended use and in compliance with the National Electrical Code, Canadian Electrical Code, and all Local and Provincial Codes.
- Follow product label information and instructions.
- Qualified Personnel must perform all servicing or relamping of this product.
- Before wiring to power supply and during servicing or relamping, turn off power at fuse or circuit breaker before service.
- The use of accessory equipment not recommended by the manufacturer or installed contrary to instructions may cause an unsafe condition. The use of damaged components may cause an unsafe condition and void product warranty.
- Do not block light emanating from product in whole or part, as this may cause an unsafe condition.
- Never operate the fixture with missing or damaged lens. Lens must be cleaned on regular basis.
- Entire fixture may become extremely hot. Do not touch hot lens or fixture body. Do not touch the lamp at any time. Use a clean, dry, soft cloth to handle the lamp. Oil from skin may damage the lamp and cause it to rupture.
- Replace lamp only with correct wattage and type of lamp marked on fixture label.
- All gaskets, o-rings and sealing surfaces must be kept clean during installation and service; failure to do this may cause an unsafe condition and void product warranty.



IMPORTANT LISTINGS AND CERTIFICATIONS

- Suitable for wet locations

RIO - 2090



HUME - 2090



IMPORTANT SAFETY INFORMATION - READ, FOLLOW, AND SAVE THESE INSTALLATION INSTRUCTIONS


B-K LIGHTING

40429 Brickyard Drive • Madera, CA 93636 • USA
559.438.5800 • FAX 559.438.5900
www.bklighting.com • info@bklighting.com

RELEASE DATE
03/24/2022

REFERENCE NUMBER
INS-2865-00


THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION OF B-K LIGHTING, INC. AND ITS RECEIPT OR POSSESSION DOES NOT CONVEY ANY RIGHTS TO REPRODUCE, DISCLOSE ITS CONTENTS, OR TO MANUFACTURE, USE OR SELL ANYTHING IT MAY DESCRIBE. REPRODUCTION, DISCLOSURE OR USE WITHOUT SPECIFIC WRITTEN AUTHORIZATION OF B-K LIGHTING, INC. IS STRICTLY FORBIDDEN.




POLE TOP

Standard Installation


Fixture Installation



1. Place machined aluminum slip fit base over pole with 2-3/8" dia. 4" tall tenon. Secure base to tenon using four (4) 1/4-20 set screws with a 3/16" allen wrench.




2. Pull primary branch circuit wiring through top of pole.




3. Ground primary branch circuit to green fixture wire. Make watertight connections from fixture primary sides to primary branch circuit wiring using waterproof wire connectors **See wiring diagram.**

⚠ Leave enough lead lengths for future service.




WIRING DIAGRAM - INC

Pull branch circuit wiring. Make watertight connections from primary branch circuit to pre-wired fixture head leads using waterproof wire connectors. **See wiring diagram.**




WIRING DIAGRAM - 0-10

Pull branch circuit wiring. Make watertight connections from primary branch circuit to pre-wired fixture head leads using waterproof wire connectors. **See wiring diagram.**



4. Place wiring connections inside pole and slide fixture over installed slip fit. Tighten three (3) #10-32 set screws with a 5/32" allen wrench. Make sure fixture is completely seated.



5. **For Future Service:** Remove top of pole by loosening three (3) #10-32 screws with a 5/32" allen wrench.

**IMPORTANT SAFETY INFORMATION LISTED ON REVERSE
READ, FOLLOW, AND SAVE ALL SAFETY AND INSTALLATION INSTRUCTIONS**




B-K LIGHTING

40429 Brickyard Drive • Madera, CA 93636 • USA
559.438.5800 • FAX 559.438.5900
www.bklighting.com • info@bklighting.com

RELEASE DATE
03/24/2022


REFERENCE NUMBER
INS-2865-00




Standard Installation

POLE TOP


360HD Knuckle



1. Use a 3/16" allen wrench to slightly loosen one (1) 3/8"-16 x 3/8" stainless steel black oxide set screw on the stem for 360° aiming purpose.



2. Rotate fixture at base and aim fixture to desired horizontal location.
3. Use a 3/16" allen wrench to loosen one (1) 1/4"-28 x 1-1/4" stainless steel black oxide socket head cap screw at the knuckle for vertical aiming purpose.




4. Tighten one (1) 3/8"-16 x 3/8" stainless steel black oxide set screw on the stem to secure horizontal aiming position.


Tighten one (1) 1/4"-28 x 1-1/4" stainless steel black oxide socket head cap screw to 24" minimum to 48" maximum pounds to secure vertical aiming position.

Warning: Do not over tighten set screw. Doing so will compromise o-ring seal and will void warranty.


360SL Knuckle



1. Use a 5/64" allen wrench to slightly loosen two (2) #8-32 stainless steel set screws on the stem for 360° aiming purpose.



2. Rotate fixture at base and aim fixture to desired horizontal location.



3. Use a 5/32" allen wrench to loosen #10-32 stainless steel black oxide socket head cap screw at the knuckle for vertical aiming purpose.
4. Tighten two (2) #8-32 stainless steel set screws on stem to secure horizontal aiming position.

Tighten #10-32 stainless steel black oxide socket head cap screw to 15" minimum to 30" maximum pounds to secure vertical aiming position.

Warning: Do not over tighten set screws. Doing so will compromise o-ring seal and will void warranty.

**IMPORTANT SAFETY INFORMATION LISTED ON REVERSE
READ, FOLLOW, AND SAVE ALL SAFETY AND INSTALLATION INSTRUCTIONS**



B-K LIGHTING

40429 Brickyard Drive • Madera, CA 93636 • USA
559.438.5800 • FAX 559.438.5900
www.bklighting.com • info@bklighting.com

RELEASE DATE
03/24/2022

REFERENCE NUMBER
INS-2865-00