







TOOLS

5/64", 9/64" & .050" Allen Wrench

DENALI UPLIGHT

FLUSH MOUNT

Waterproof Wire Connector

INSTRUCTIONS PERTAINING TO A RISK OF FIRE, OR INJURY **TO PERSONS IMPORTANT SAFETY INSTRUCTIONS**

Lighted fixture is HOT! WARNING - To reduce the risk of FIRE OR INJURY TO PERSONS:

Turn off/unplug and allow to cool before replacing lamp/LED. Fixture gets HOT quickly! Contact only switch/plug when turning on. Do not touch hot lens, guard, or enclosure. Keep fixture away from materials that may burn. Do not operate the luminaire fitting with a missing or damaged shield. Do not touch the source at any time. Use a soft cloth or gloves. Oil from skin may cause damage.

SAVE THESE INSTRUCTIONS

IMPORTANT SAFETY INFORMATION - READ, FOLLOW, AND SAVE ALL SAFETY AND INSTALLATION INSTRUCTIONS

- · Product must be installed by a qualified person in a manner consistent with its intended use and in compliance with the National Electrical Code, Canadian Electrical Code, and all Local and Provincial Codes
- Follow product label information and instructions
- · Qualified Personnel with appropriate personal protective equipment must perform all servicing of this product.
- · Before wiring to power supply and during servicing, turn off and lock out power at fuse or circuit breaker before service.
- The use of accessory equipment not recommended by the manufacturer or installed contrary to instructions may cause an unsafe condition. The use of damaged components may cause an unsafe condition and void product warranty.
- · Do not block light emanating from product in whole or part, as this may cause an unsafe condition
- · Never operate the fixture with missing or damaged lens. Lens must be cleaned on regular basis.
- · Entire fixture may become extremely hot. Do not touch hot lens or fixture body.
- · Replace LED assembly only with correct wattage and type of power supply appropriate for LED assembly.
- All gaskets, o-rings and sealing surfaces must be kept clean during installation and service; failure to do this may cause an unsafe condition and void product warranty.

IMPORTANT LISTINGS AND CERTIFICATIONS

· Suitable for wet locations

Proper soil preparation is recommended before installation. See the DIG-IT guide at www.bklighting.com/collaterals/install/digit.pdf for more information.

/INREMOTE WIRING

Failure to comply with specific wiring requirements will void product warranty. **DRIVER HOUSING REQUIRED**


documentation for detailed installation instructions

HP2RM - HP2 Remote Housing PM2RM - Universal Power Module 2 Remote

RM - Remote Wall Mount

- Dual Remote Wall Mount

Driver manufacturers regularly



PM2RM & PM2DRM HP2RM RM & DRM

DRM

IMPORTANT SAFETY INFORMATION - READ, FOLLOW, AND SAVE THESE INSTALLATION INSTRUCTIONS


B-K LIGHTING

40429 Brickyard Drive • Madera, CA 93636 • USA 559.438.5800 • FAX 559.438.5900 www.bklighting.com • info@bklighting.com	RELEASE DATE	REFERENCE NUMBER
	07/31/2023	INS-2318-00


THIS DOCUMENT CONTAINS PROPRIETARY INFORMATION OF B-K LIGHTING, INC. AND ITS RECEIPT OR POSSESSION DOES NOT CONVEY ANY RIGHTS TO REPRODUCE, DISCLOSE ITS CONTENTS, OR TO MANUFACTURE, USE OR SELL ANYTHING IT MAY DESCRIBE. REPRODUCTION DISCLOSUBE OR USE WITHOUT SPECIFIC WRITTEN AUTHORIZATION OF B-K LIGHTING, INC. IS STRICTLY FORBIDDEN




Soil Prep




Determine Soil Type by referencing DIG-IT Guide. B. Dig hole 15" wide and 12" deep. Prep soil according to DIG-IT Guide. Α.






C. Prep soil according to DIG-IT Guide.


Fixture Installation




- Excavate trench according to designed lighting 1. plan 15" deep and 12" wide suitable for the fixture housina.
- 2. Supply remote wiring necessary for installation.




- Slide stability flange onto housing. 3.
- NOTE: Product is supplied with a stability flange ⚠ to anchor fixture and aid in installation.



- Loop minimum of 6" of low voltage wire inside 4. housing to allow for fixture service. Place fixture in hole.
- ▲ NOTE: Do not remove temporary cover!



- 5. Align holes to final installation orientation. Arrows on temporary cover point towards screw location on faceplate for alignment purposes.
- $\underline{\land} \ \ \, \hbox{NOTE: Do not remove temporary cover until} \\ \underline{\land} \ \ \, \hbox{installation of faceplate.}$
- Rebar or Stake (Not Included) Stability Flange Concrete Finished Grade Pea Gravel or Sand
- 6. Per DIG-IT Guide, backfill the gap between the bottom of housing and bottom of hole with sand or pea gravel for drainage.
- ▲ NOTE: The mounting collar must be flush to finished grade. Use stability flange to aid in installation as shown.



7. Fill the hole around the fixture housing to 12" below the finished grade with clean fill dirt and tamp carefully to prevent settling of fixture. Pour concrete and finish as required flush with mounting collar.

US

IMPORTANT SAFETY INFORMATION LISTED ON REVERSE READ, FOLLOW, AND SAVE ALL SAFETY AND INSTALLATION INSTRUCTIONS




40429 Brickvard Drive • Madera, CA 93636 • USA 559.438.5800 • FAX 559.438.5900 www.bklighting.com • info@bklighting.com

RELEASE DATE REFERENCE NUMBER 07/31/2023 INS-2318-00






8. Remove temporary cover and pull out remote 9. wiring.




 Access remote wiring inside housing. Make watertight connections using waterproof wire connectors, matching polarity. Fixture leads are labeled. Wire nuts must clear opening. Insert fixture, wiring and connections into housing. See wiring diagram.



WIRING DIAGRAM

Marning: Fixture leads are labeled. Do not reverse polarity. This will void warranty.



 Mount faceplate to collar using two (2) #8-32 flat head screws (included) with a 9/64" allen wrench.

IMPORTANT SAFETY INFORMATION LISTED ON REVERSE READ, FOLLOW, AND SAVE ALL SAFETY AND INSTALLATION INSTRUCTIONS



INS-2318-00




40429 Brickyard Drive • Madera, CA 93636 • USA 559.438.5800 • A FAX 559.438.5900 www.bklighting. RELEASE DATE 07/31/2023




This product is available with field replaceable components. Exclusive interchangeable OPTIKITS and modular LED components with quick disconnects simplifies upgrades and maintenance when necessary.


Fixture Relamping




 Remove faceplate from collar using two (2) #8-32 faceplate screws (included) with a 9/64" allen wrench.




2. Remove fixture from collar.




3. Loosen three (3) #8-32 set screws with a 5/64" allen wrench to remove cap.



4. Remove optic by turning to the left and lift up. Unscrew fasteners on optic holder using a .050" allen wrench, grasp optic holder and gently pull upward to remove LED component. Install optic holder onto new LED component and reverse installation onto fixture body.



5. Tighten three (3) #8-32 set screws with a 5/64" allen wrench to install cap.



 Replace faceplate, then replace fixture in mounting collar. Mount cap to collar using two (2) #8-32 flat head screws (included) with a 9/64" allen wrench. Do not overtighten.

IMPORTANT SAFETY INFORMATION LISTED ON REVERSE READ, FOLLOW, AND SAVE ALL SAFETY AND INSTALLATION INSTRUCTIONS



INS-2318-00



40429 Brickyard Drive • Madera, CA 93636 • USA 559.438.5800 • A FAX 559.438.5900 www.bklighting. com • info@bklighting.com RELEASE DATE 07/31/2023



LED BOARD / OPTICS

CHIP ON BOARD TECHNOLOGY (x58-63)

Standard	Installation	Replacement



Provincial Codes

TOOLS

IMPORTANT SAFETY INFORMATION - READ, FOLLOW, AND SAVE ALL

SAFETY AND INSTALLATION INSTRUCTIONS

NEEDED:

.050" & 5/64" Allen Wrench

· Product must be installed by a gualified person in a manner Do not block light emanating from product in whole or part, as

- this may cause an unsafe condition. · Never operate the fixture with missing or damaged lens.
 - Lens must be cleaned on regular basis.
 - · Entire fixture may become extremely hot. Do not touch hot lens or fixture body
 - Replace LED assembly only with correct wattage and type of power supply appropriate for LED assembly.
 - · All gaskets, o-rings and sealing surfaces must be kept clean during installation and service; failure to do this may cause an unsafe condition and void product warranty.

INSTRUCTIONS PERTAINING TO A RISK OF FIRE, OR INJURY TO PERSONS IMPORTANT SAFETY **INSTRUCTIONS**

Lighted fixture is HOT! WARNING - To reduce the risk of FIRE OR INJURY TO PERSONS:

off/unplug and allow to cool before Turn replacing lamp/LED. Fixture gets HOT quickly! Contact only switch/plug when turning on. Do not touch hot lens, guard, or enclosure. Keep fixture away from materials that may burn. Do not operate the luminaire fitting with a missing or damaged shield. Do not touch the source at any time. Use a soft cloth or gloves. Oil from skin may cause damage.

SAVE THESE INSTRUCTIONS

IMPORTANT LISTINGS AND CERTIFICATIONS

consistent with its intended use and in compliance with the

National Electrical Code, Canadian Electrical Code, and all Local and

Qualified Personnel with appropriate personal protective

Before wiring to power supply and during servicing, turn off and

· The use of accessory equipment not recommended by the

manufacturer or installed contrary to instructions may cause an

unsafe condition. The use of damaged components may cause an

Follow product label information and instructions


unsafe condition and void product warranty.

equipment must perform all servicing of this product.


lock out power at fuse or circuit breaker before service

· Suitable for wet locations


This product is available with field replaceable components. Exclusive interchangeable modular LED components with quick disconnects simplifies upgrades and maintenance when necessary.




Use a 5/64" allen wrench to slightly loosen 2. Remove optic by pulling gently and lift up. 1. three (3) #8-32 stainless steel set screws to remove cap.




- Gently lift LED module and disconnect from fixture. 4. Install new LED module. Secure set screws through LED module and optic holder using a .050" allen wrench.
- $\underline{\bigwedge}$ Do not pull on connector or wiring. Handle with care.






5. Replace optic by lining tabs with optic holder, then pressing down gently until secured into place.



Use a .050" allen wrench to loosen three (3) set 3. screws holding optic holder and LED module.



- fixture Place 6. cap on and tighten set until they are flush with the screws cap.
- Warning: Do not over tighten set screws. Doing so will compromise o-ring seal and will void 么 warranty. Cap should be able to rotate without force.

IMPORTANT SAFETY INFORMATION - READ, FOLLOW, AND SAVE THESE INSTALLATION INSTRUCTIONS

B-K LIGHTING

40429 Brickvard Drive • Madera, CA 93636 • USA 559.438.5800 • FAX 559.438.5900 www.bklighting.com • info@bklighting.com

RELEASE DATE REFERENCE NUMBER 07/31/2023 INS000010



LED BOARD / OPTICS

CHIP ON BOARD TECHNOLOGY (x64-x66)

)	Standard	Installation	Replacement
---	----------	--------------	-------------

INSTRUCTIONS PERTAINING TO A RISK OF FIRE, OR INJURY TO PERSONS IMPORTANT SAFETY **INSTRUCTIONS**

Lighted fixture is HOT! WARNING - To reduce the risk of FIRE OR INJURY TO PERSONS:

off/unplug and allow to cool before Turn replacing lamp/LED. Fixture gets HOT quickly! Contact only switch/plug when turning on. Do not touch hot lens, guard, or enclosure. Keep fixture away from materials that may burn. Do not operate the luminaire fitting with a missing or damaged shield. Do not touch the source at any time. Use a soft cloth or gloves. Oil from skin may cause damage.

SAVE THESE INSTRUCTIONS



TOOLS NEEDED: .050" & 5/64" Allen Wrench


IMPORTANT SAFETY INFORMATION - READ, FOLLOW, AND SAVE ALL SAFETY AND INSTALLATION INSTRUCTIONS

- · Product must be installed by a gualified person in a manner consistent with its intended use and in compliance with the National Electrical Code, Canadian Electrical Code, and all Local and Provincial Codes
- Follow product label information and instructions
- Qualified Personnel with appropriate personal protective equipment must perform all servicing of this product.
- Before wiring to power supply and during servicing, turn off and lock out power at fuse or circuit breaker before service
- · The use of accessory equipment not recommended by the manufacturer or installed contrary to instructions may cause an unsafe condition. The use of damaged components may cause an unsafe condition and void product warranty.
- Do not block light emanating from product in whole or part, as this may cause an unsafe condition.
- · Never operate the fixture with missing or damaged lens. Lens must be cleaned on regular basis.
- · Entire fixture may become extremely hot. Do not touch hot lens or fixture body
- Replace LED assembly only with correct wattage and type of power supply appropriate for LED assembly.
- · All gaskets, o-rings and sealing surfaces must be kept clean during installation and service; failure to do this may cause an unsafe condition and void product warranty.


IMPORTANT LISTINGS AND CERTIFICATIONS

· Suitable for wet locations


This product is available with field replaceable components. Exclusive interchangeable modular LED components with quick disconnects simplifies upgrades and maintenance when necessary.




Use a 5/64" allen wrench to slightly loosen 2. Remove optic by pulling gently and lift up. 1. three (3) #8-32 stainless steel set screws to remove cap.




- Gently lift LED module and disconnect from fixture. 4. Install new LED module. Secure set screws using a .050" allen wrench.
- $\underline{\bigwedge}$ Do not pull on connector or wiring. Handle with care.






5. Replace optic by lining notches with optic holder, then pressing down gently until secured into place.



Use a .050" allen wrench to loosen three (3) set 3. screws holding LED module. Gently lift from fixture.



- fixture Place 6. cap on and tighten set until they are flush with the screws cap.
- Warning: Do not over tighten set screws. Doing ⚠ so will compromise o-ring seal and will void warranty. Cap should be able to rotate without force.

IMPORTANT SAFETY INFORMATION - READ, FOLLOW, AND SAVE THESE INSTALLATION INSTRUCTIONS

B-K LIGHTING

40429 Brickvard Drive • Madera, CA 93636 • USA 559.438.5800 • FAX 559.438.5900 www.bklighting.com • info@bklighting.com

RELEASE DATE REFERENCE NUMBER 07/31/2023 INS000010